

Fork Mounted Poles

Model - IFB



Description

As with the Carriage Mounted Pole the **Fork Mounted Pole** is capable of lifting a variety of coiled products, but is usually used in low volume / occasion usage environment with a mixed pallet / coiled product application.

Model	Boom dia (mm)	Effective Length (mm)	Capacity (kg)	Load Centre (mm)	Weight (kg)	C of G (mm)	LLC (mm)
IFB-1	70	3000	500	2000	210	790	950
IFB-2	75	3000	750	2000	225	960	950
IFB-3	75	3500	750	2500	240	1060	950

Standard Features

- High tensile machined pole with tapered tip to ease location into coiled product
- Free standing for ease of location
- Smooth surface finish to protect the intended load to be lifted
- Zinc plated heel pins for safe attachment to truck
- Maximum fork section 125 x 50 mm at 230 centres
- Painted bright orange for safety

What we need to know for a quotation:

- Product length, weight, Internal x External diameters



TECHNICAL FILE
OPERATION, MAINTENANCE, & HEALTH AND SAFETY INSTRUCTIONS
MODEL: FORK MOUNTED CARPET POLE

Operation

1. Position the forks the correct distance apart to locate into fork pockets.
2. Remove fork pocket heel pins from fork pockets.
3. Drive forks into the fork pockets.
4. Insert fork pocket heel pins directly behind heel of fork and attach safety lynch pin into hole provided.
5. The attachment is now ready for use.

Maintenance

1. The Fork Mounted Carpet Pole should be inspected weekly for general condition with particular attention paid to:
 - A – All weld points.
 - B – Wear and distortion of fork pockets and heel pin attachments.
 - C – Any damaged components.
 - D – Pole alignment
2. Damage or failure must be reported or rectified immediately prior re-use of Fork Mounted Carpet Pole.
3. General surface rusting especially in critical areas should be treated with proprietary inhibitors, primers and paint on a regular basis.
4. This product is certified for six (6) months from the date of manufacture after which it is the customer's responsibility to have the product re-tested at an approved testing facility or inspected and logged in a register by a competent person as advised by the HSE.

Health and Safety

1. The manager of the department or section where the attachment is to be used must be responsible for ensuring the operators are fully conversant with the attachment, its operation, maintenance and that the heel pins are fitted correctly.
2. Ensure both the truck and attachments are capable of handling the intended load and its contents.
3. Do not drive into the fork pockets without removing the heel pins.
4. Ensure that the heel pins are correctly inserted, retained and positioned in relation to the heel of the fork prior to each use.
5. Ensure the attachment is level when entering the carpet core.
6. Do not shock load the attachment under any circumstances.
7. The safe working load must not be exceeded at its load centre.
8. Always fully insert the effective length of the pole down the carpet core. Do not tip load.

The Operator should ensure that the above product is used for the purpose that it has been designed, tested and intended to do and no deviation to this occurs. If in doubt, consult your fork truck dealer or approved attachment supplier.